TASK FORCE LOCKER ASSEMBLY INSTRUCTIONS

PLEASE READ INSTRUCTIONS CAREFULLY BEFORE BEGINNING ASSEMBLY.

General Instructions

- 1. Check material received against the packing list. First, check the number of packages received and then check the contents of each package.
- 2. Check the material received for damage. If damage occurred, secure a "damage notation" from the carrier.
- 3. Identify each part as it is unpacked and put like parts together as soon as possible to the working area where they are to be assembled.
- 4. Be careful to use the correct hardware as specified in assembly.

CAUTION

IN THE INTEREST OF SAFETY. ALL LOCKERS MUST BE SECURELY ANCHORED TO THE FLOOR AND/OR WALL. FOR SAFETY. HANDLE ALL COMPONENTS CAREFULLY AND WEAR WORK-GLOVES WHEN ASSEMBLING LOCKERS. INSTALL ALL UNITS PLUMB AND TIGHTEN ALL HARDWARE SECURELY RETAIN INSTRUCTIONS FOR FUTURE REFERENCE




2823 W. Orange Ave. Apopka, FL 32703 Ph: 407-464-3611 **www.hallowell-list.com**


INSTALLING THE LATCH COVER PLATE

THESE BLANK PLATES ARE USED FOR A STAND-ALONE LOCKER (WITHOUT A DRAWER UNIT) WHEN A DRAWER UNIT IS BEING INSTALLED, SEE SHEET **2**

- 1. OPEN RIGHT DOOR
- 2. INSTALL PLATE USING (2) MS124 #8 SELF TAPPING SCREWS. SEE DETAIL A & B



DETAIL A



DETAIL B

UNLESS OTHERWISE SPECIFIED		Ш	all	OV	MALL	0	
INCHES XX. ± .010 XXX. ± .005	Hallowell-List.com						
FRACTIONAL X/X. ± 1/64	2823 W. ORANGE AVE. Tel (866) 566-050 APOPKA, FLORIDA 32703 Fax (407) 464-361						
ANGULAR	DRAWN BY	DATE	DESCR	IPTION			
∠ ± 1/2°	ROW	8/19/2022	'	TASK	FORC	E BLANK	
UNLESS OTHERWISE SPECIFIED ALL	CHECKED BY	DATE		PLA	TE TO	LOCKER	
DIMENSIONS ARE IN INCHES, METRIC					ASSEM	BLY	
DIMENSIONS WILL BE	APPROVED BY	DATE	SCALE	SHEET	PART NO.	DRAWING NO.	REV.
WITHIN [XX]			:	1 OF 5		SA4290	

THIS DRAWING AND THE INFORMATION ON IT IS THE CONFIDENTIAL PROPERTY OF HALLOWELL, AND SHALL NOT BE COPIED OR DISCLOSED TO OTHERS WITHOUT WRITTEN PERMISSION, ONLY HALLOWELL RESERVES THE RIGHT TO ALTER ANY DESIGN, ANY UNAUTHORIZED MODIFICATIONS RELEASES HALLOWELL FROM ALL LIABILITIES


INSTALLING THE LOCKER ON THE DRAWER UNIT

- 1. REMOVE THE DRAWER ASSEMBLY, SEE SHEET 5.
- 2. IF INSTALLING THE BASE UNIT TO THE FLOOR BEFORE MOUNTING THE LOCKER, SEE NUMBER 5.
 PLACE THE LOCKER ON TOP OF THE BASE UNIT. MAKE LOCKER AND BASE UNIT FLUSH AT THE BACK. CENTER LOCKER RIGHT TO LEFT ON THE BASE UNIT.
- 2 PCS. 3. USING A NAIL SET TOOL OR TAPERED PIN, LINE UP THE TWO HOLES IN THE BASE UNIT WITH THE TWO HOLES IN THE BOTTOM FLANGE ON THE LOCKER. IT MAY BE HELPFUL TO LIFT THE FRONT OF THE LOCKER
 TO SEE THE HOLES IN THE FLANGE. SCREW IN THE (2) MS124 SCREWS (FROM INSIDE BASE TO LOCKER). SEE DETAIL **B** & **C**4. BOLT TWO UNITS TOGETHER USING (2) MS113, (2) N107 & (2) W118. SEE DETAIL **B**.

 5. PUT IN PLACE AND ANCHOR TO THE FLOOR THROUGH BOTTOM OF BASE UNIT. DRILL HOLES IN BASE UNIT 12" FROM

FRONT, 3" FROM EACH SIDE (ANCHORS BY OTHERS).

6. IF INSTALLING A WOOD SEAT SEE SHEET 4.



MS124

MS113

2 PCS.

MOUNTING THE LOCKING LATCH TO THE LOCKER


- 1. OPEN RIGHT DOOR, OPEN DRAWER ABOUT 4".
- 2. INSERT THE LATCH ASSEMBLY IN THE CUTOUT IN THE FRONT OF THE LOCKER. SEE DETAIL **D**. IT MAY BE NECESSARY TO JIGGLE THE LATCH WHILE INSERTING SO IT GOES DOWN INTO THE BASE UNIT. THE LATCH GOES INTO THE SLOTS IN THE TOP OF THE BASE UNIT. SEE DETAIL **E**. SEE SHEET **4** FOR DETAIL OF LATCH ASSEMBLY.
- 3. SCREW IN (2) MS124 SCREWS. SEE DETAIL E.
- 4. TEST LATCH: AFTER THE LATCH IS MOUNTED TO THE LOCKER, MAKE SURE THAT THE LATCH BOLT MOVES UP AND DOWN FREELY. SEE DETAIL **E**. IF NOT, LOOSEN SCREW AND MOVE LATCH AROUND AND RE-TIGHTEN THE SCREWS. ALSO THE DRAWER NEED TO BE FULLY CLOSED OR OPEN ABOUT 2" FOR THE BOLT TO MOVE UP AND DOWN. WITH THE RIGHT DOOR OPEN, MAKE SURE THAT THE DRAWER OPENS AND CLOSES. WITH THE DRAWER FULLY CLOSED, CLOSE DOOR AND MAKE SURE THE DRAWER IS LOCKED. LASTLY OPEN THE DOOR, OPEN THE DRAWER, CLOSE THE DOOR AND CLOSE THE DRAWER. THE DRAWER SHOULD CLOSE AND LOCK.



LATCH DROPS INTO THE SLOT IN THE TOP OF THE BASE UNIT:



DETAIL D



TOLERANCES

UNLESS OTHERWISE SPECIFIED


INCHES XX. ± .010 XXX. ± .005	www.Hallowell-List.com							
FRACTIONAL X/X. ± 1/64	2823 W. ORANGE AVE. APOPKA, FLORIDA 32703				Tel (866) 566-0500 Fax (407) 464-3610			
ANGULAR	DRAWN BY	DATE	DESCRIPTION					
∠ ± 1/2°	ROW	8/19/2022	т	A CIZ I	EODCE I	ATCH T	0	
UNLESS OTHERWISE	CHECKED BY	DATE					U	
SPECIFIED ALL DIMENSIONS ARE IN INCHES, METRIC				LOC	KER ASS	SEMBLY		
DIMENSIONS WILL BE WITHIN [XX]	APPROVED BY	DATE	SCALE	SHEET	PART NO.	DRAWING NO.	REV.	
			:	3 OF 5		SA4290		

Hallowell

THIS DRAWING AND THE INFORMATION ON IT IS THE CONFIDENTIAL PROPERTY OF HALLOWELL. AND SHALL NOT BE COPIED OR DISCLOSED TO OTHERS WITHOUT WRITTEN PERMISSION, ONLY HALLOWELL RESERVES THE RIGHT TO ALTER ANY DESIGN, ANY UNAUTHORIZED MODIFICATIONS RELEASES HALLOWELL FROM ALL LIABILITIES.

ATTACHING THE WOOD SEAT TO THE BASE

- 1. PLACE THE WOOD SEAT UP AGAINST THE FRONT OF THE CABINET AND CENTER LEFT TO RIGHT.
- 2. ATTACH THE WOOD SEAT USING (4) SMS105 SCREWS THRU THE 1/4" HOLES IN THE TOP OF THE DRAWER UNIT.





SMS105


THIS DRAWING AND THE INFORMATION ON IT IS TH	IE CONFIDENTIAL PROPERTY OF HALLOWELL	AND SHALL NOT BE COPIED OR DISCLOSED TO OTHERS
WITHOUT WRITTEN PERMISSION, ONLY HALLOWEL	L RESERVES THE RIGHT TO ALTER ANY DESIG	GN. ANY UNAUTHORIZED MODIFICATIONS RELEASES
HALLOWELL FROM ALL LIABILITIES.		


ITEM NO.	PART NUMBER	DESCRIPTION	QTY.
1	SLP-DI	SLAM LATCH PLATE, DROP IN	1
2	SL-CV	SLAM LATCH COVER PLATE	1
3	SL-CAB-A	SLAM LATCH-CABINET	1
4	MS124	8-32 X 3/8 THREAD CUTTING PAN HEAD SCREW	6

SLAM LATCH ASSEMBLY

THIS LATCH GETS INSTALLED INTO THE LOCKER.

- 1. USING (4) MS124 SCREWS, ATTACH THE LATCH ASSEMBLY TO THE LATCH PLATE.
- 2. PLACE THE COVER PLATE UNDER THE LATCH PLATE.
- **3.** PUT THE (2) MS124 SCREWS INTO THE LATCH PLATE AND THE COVER PLATE.






TOLERANCES UNLESS OTHERWISE SPECIFIED			al	OV	vell®		
INCHES XX. ± .010 XXX. ± .005					List.com		
FRACTIONAL X/X. ± 1/64	2823 W. ORANGE AVE. APOPKA, FLORIDA 32703					Tel (866) 566-03 Fax (407) 464-3	
ANGULAR	DRAWN BY	DATE	DESCR	IPTION			
∠ ± 1/2°	ROW	8/19/2022	TAS	SK FO	RCE LO	CKER WO	OD
UNLESS OTHERWISE	CHECKED BY	DATE] S	SEAT A	AND SLA	M LATCE	I
SPECIFIED ALL DIMENSIONS ARE IN INCHES, METRIC					ASSEMB	LY	
DIMENSIONS WILL BE	APPROVED BY	DATE	SCALE	SHEET	PART NO.	DRAWING NO.	REV.
WITHIN [XX]			:	4 OF 5		SA4290	

INSTRUCTION FOR REMOVING THE DRAWER

- 1. OPEN THE DRAWER TO THEIR FULL EXTENT
- 2. EACH SLIDE HAS A SMALL LEVER IN THE MIDDLE OF IT FOR REMOVAL.



3. PUSH DOWN ON THE RIGHT LEVER AND UP ON THE LEFT LEVER.



PUSH DOWN ON THIS LEVER-



- **4.** AS YOU PUSH BOTH LEVERS, PULL DRAWER EVENLY TOWARDS YOU. **5.** PULL THE DRAWER ALL THE WAY OUT UNTIL IT IS FULLY REMOVED FROM THE BASE UNIT.

UNLESS OTHERWISE SPECIFIED	Hallowell							
INCHES XX. ± .010 XXX. ± .005	www.Hallowell-List.com							
FRACTIONAL X/X. ± 1/64	2823 W. OR APOPKA, F	Tel (866) 566-0500 Fax (407) 464-3610						
ANGULAR	DRAWN BY	DATE	DESCR	IPTION				
∠ ± 1/2°	ROW	8/19/2022	7	ACIZ	EODCE	LOCKER		
UNLESS OTHERWISE	CHECKED BY	DATE						
SPECIFIED ALL DIMENSIONS ARE IN INCHES. METRIC DIMENSIONS WILL BE				DRA	WER RE	MOVAL		
	APPROVED BY	DATE	SCALE	SHEET	PART NO.	DRAWING NO.	REV.	
WITHIN [XX]			:	5 OF 5		SA4290		

THIS DRAWING AND THE INFORMATION ON IT IS THE CONFIDENTIAL PROPERTY OF HALLOWELL. AND SHALL NOT BE COPIED OR DISCLOSED TO OTHERS WITHOUT WRITTEN PERMISSION. ONLY HALLOWELL RESERVES THE RIGHT TO ALTER ANY DESIGN. ANY UNAUTHORIZED MODIFICATIONS RELEASES HALLOWELL FROM ALL LIABILITIES.